



# HUMIE

*Humidity and Temperature Sensor*




Add sensor and see install instructions  
at [app.alertlabs.com/addsensor](https://app.alertlabs.com/addsensor)

1

Add sensor and see install instructions at [app.alertlabs.com/addsensor](http://app.alertlabs.com/addsensor)




2




Serial Number

3



OR



For indoor humidity and temperature monitoring. Keep dry.

## NOTES

Property: \_\_\_\_\_  
\_\_\_\_\_

Location: \_\_\_\_\_  
\_\_\_\_\_