

## Product Image




## Plate Straps

Plate straps are nailed across studs to restrain pipe. They are also used to protect utility pipes & electrical wire that pass through wood studs from being pierced by drills, nails or fasteners.

### Installation Instructions:

1. Ensure all surfaces are clean of dust and debris.
2. Carefully align the plate onto the stud and over the desired area needing protection.
3. Using the mounting holes provided, screw the plate into place creating a protective steel shield on the stud.

## Product Dimensions



PN#	Size	Gauge	A	B	C
			mm		
PS129	1-1/2" x 9"	12	38	223	2.4
PS1212	1-1/2" x 12"	12	38	300	2.4
PS1218	1-1/2" x 18"	12	38	450	2.4
PS1224	1-1/2" x 24"	12	38	603	2.4
PS169	1-1/2" x 9"	16	38	223	1.4
PS1612	1-1/2" x 12"	16	38	300	1.4
PS1618	1-1/2" x 18"	16	38	450	1.4
PS1624	1-1/2" x 24"	16	38	603	1.4

## Product Characteristics

**Tolerances**

+/- 0.2mm